



Wood + Concrete Kitchen Island



A DIY KITCHEN ISLAND WITH A CONCRETE COUNTERTOP

This sturdy kitchen Island can be used indoors or outside. The wood base is made from 2x4s, 1x4s, and stainless steel screws. The top is a 2.5" thick concrete slab made with Quikrete Countertop Mix and reinforced with 1/2" diameter rebar.



STEP 1


Make the concrete top first before measuring and cutting the wood for the base. The concrete should overhang the base by at least 1/2".

STEP 2

Cut the wood.

CUT LIST:

a	2x4 - 39"	x 2
b	2x4 - 14"	x 2
c	2x4 - 30"	x 4
d	1x4 Field Measure (d) Pieces	x 4
e	2x4 - 36.5"	x 2
f	1x4 - 14"	x 2
g	1x4 - 36.5"	x 3
h	2x4 - 11"	x 3



STEP 3

Screw together the bottom tray.

STEP 4

Screw together the top frame and legs.

STEP 5

Slide the bottom tray between the legs.

STEP 6

Raise the bottom tray up 3 1/2".

STEP 7

Screw through the legs into the bottom tray.

STEP 8

Take field measurements for the top trim (d) pieces.

STEP 9

Cut the trim pieces and screw them into place.

STEP 10

Lift the concrete into place and connect with construction adhesive or screw through (a) pieces.

